


# COVE TR INSTALLATION

## Components & Hardware



(A) Cove TR, Qty. 1  
(corded pictured)



(B) P-Clamp, Qty. 2



(C) #8 x .75", Qty. 2

## Tools Needed



**Note:** A licensed electrician should make the hardwire connections. For use on dry work surfaces or furniture only. No serviceable parts, do not disassemble.

## Installation Instructions:

- 1-** Use recommended cutout and prepare the surface.
- 2-** Insert the Cove through the cutout.
- 3-** For clamping Cove - Bend the tabs of the cove until folded under the table as shown. Optional, use the screw holes provided to further secure the Cove TR.
- 4-** Use P-Clamps (B) and remaining screws (C) to route cable and attach to underside of work surface as needed.
- 5-** Connect power and data as needed.
- 6-** Connections for hardwire units:  
Black wire – circuit hot  
White wire – circuit neutral  
Green wire – circuit ground

