

STUDIO

BY DEKKO 2505 Dekko Drive
Garrett, IN 46738
Customer Service: 800.357.5622


ASHLEY LINK 30

- Corded -


Above Worksurface Mounting Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Tools Required




1 Slide Bracket Behind Worksurface




* Top of Worksurface *

2 Install Bottom Bracket Under the Worksurface




* Underside of Worksurface *

3 Secure Thumb Screws and Route Power Cord Option to Nearest Power Distribution Source



#8 x 1/2" Pan Head Screw



* Underside of Worksurface *

-Optional-
Power Cord
Mounting Clamps
(A) Screws

NEMA
Plug

Elevation
Detail

ASHLEY
LINK 30

* Side of Worksurface *

Worksurface
Thickness Range
(3/4" to 1-1/2")

E.C.N. No: GD18-000932

Part Number: G110305

Page Number: 1 of 1

Revision: A