

COVE DOUBLE KIT INSTALLATION

Components & Hardware

(A) Cove, Qty. 2 (See "COVE WITH DAISYLINK INSTALLATION" sheet for additional accessories)

(B) 42 FF-XX", Qty. 1

(C) 42 FF-12", Qty. 1


(D) 42 FM-12", Qty. 1

(E) P-Clamp, Qty. 8

(F) #8 x .75", Qty. 8

Tools Needed

Model	COV-2	COV-2U	COV-4	COV-4U
X Dim. (in.)	4.50"	5.25"	7.25"	8.25"



**If (C) Female/Female cable is used on the leftmost connection, it must consistently be used on the leftmost connection while (D) Female/Male cable must be consistently used on the rightmost connection.

Table Size (in.)	L Dim. (in.)			
	COV-2	COV-2U	COV-4	COV-4U
60"	33.92"	33.67"	31.67"	30.67"
66"	39.92"	39.67"	37.67"	36.67"
72"	45.92"	45.67"	43.67"	42.67"
84"	51.92"	51.67"	49.67"	48.67"
96"	57.92"	57.67"	55.67"	54.67"

Plug into an appropriate outlet that is properly installed and grounded in accordance with all local codes and regulations.