


2505 Dekko Drive  
Garrett, IN 46738  
Customer Service: 800.357.5622

# ASHLEY DUO AIR

- Conduit Feed -  
Surface Mounting  
Installation Instruction


This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Tools Required**




## 1 Cutout Opening for Ashley Duo Air Assembly

**\* NOTE \***  
Please use Template Provided on Page 2.  
Max Radius on Cutout Corners is 1/4"



## 2 Install Ashley Duo Air Assembly into Cutout


**\* NOTE \***  
Route "Power Cord" through cutout before inserting assembly into cutout.



## 3 Install Retainer Bracket

Underside of Worksurface

\* Align Tabs on Ashley Duo Air Assembly with Slots on Retainer Bracket and Slide into Fully Engaged Position \*




**\* NOTE \***  
Route Power Cord Through Notch in Retainer Bracket

## 4 Route Power Cord to Nearest Power Distribution Source

\* Tighten Screws Snug to the Bottom of the Worksurface (Qty-4) \*

Underside of Worksurface



**WIRE IDENTIFICATION**  
— LINE (BLACK)  
— GROUND (GREEN)  
— NEUTRAL (WHITE)



2505 Dekko Drive  
 Garrett, IN 46738  
 Customer Service: 800.357.5622

**ASHLEY DUO AIR**  
 - Conduit Feed -  
**Surface Mounting**  
Installation Instruction Template

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

