

DEKKO


7310 Innovation Blvd. Suite 104
Fort Wayne, IN 46818
Customer Service: 800.357.5622

COVE MICRO

Corded
Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Tools Required




1


Determine The Surface Cutout Size for the COVE MICRO Unit Being Installed

* NOTE *

Refer to chart to determine "X" dimension.




OR



Cutout Opening	"X"
USB Only	2.75in
2Power Outlets + USB	6.328in
4Power Outlets	6.328in
4Power Outlets + USB	9.906in


COVE MICRO Models



2

Install COVE MICRO Assembly into Cutout opening

COVE MICRO
2 Power



3

Secure COVE MICRO Assembly to Surface and Connect Power and Data as Needed

* NOTE *

Plug into an appropriate outlet that is properly installed and grounded in accordance with all local codes and regulations.

