

# DEKKO


7310 Innovation Blvd. Suite 104  
Fort Wayne, IN 46818  
Customer Service: 800.357.5622

## COVE MICRO

Hardwire  
Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Tools Required




# 1


### Determine The Surface Cutout Size for the COVE MICRO Unit Being Installed

#### \* NOTE \*

Refer to chart to determine "X" dimension.




OR




Cutout Opening	"X"
USB Only	2.75in
2Power Outlets + USB	6.328in
4Power Outlets	6.328in
4Power Outlets + USB	9.906in

### COVE MICRO Models



# 2

### Install COVE MICRO Assembly into Cutout opening



# 3

### Secure COVE MICRO Assembly to Surface and Connect Power and Data as Needed

#### \* NOTE \*

A licensed electrician must make the hardwire connections. For use on dry work surfaces or furniture only. No serviceable parts, do not disassemble.

