



## **INTERFACE II UT**Installation Instructions



## **Recommended Table Cutout**



## **Installation Instructions**

- 1. Use Table Cutout above for cutout size and screw locations.
- 2. Mount Interface utilizing keyholes and slide into position.
- 3. Fabricate top as required.

Innovative Power + Data Solutions