

2505 Dekko Drive  
Garrett, IN 46738  
Customer Service: 800.357.5622

## ASHLEY QUAD


- Conduit -

### Above Worksurface Mounting

#### Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


#### Tools Required



#### \*NOTE\*

All Tech Adapters Need to be Mounted in the  
⬆ "UP" ⬆ Position. (Refer to the back of Parts)


### 1 Remove Data Port Cover and Blank Adapters




### 2 Install Data Port Options (VGA, RJ45, HDMI, BLANK)

#### \*NOTE\*

See Sheet #2 for Detailed Instructions




### 3 Slide Bracket Behind Worksurface



\* Top of Worksurface \*

### 4 Install Bottom Bracket Under the Worksurface

\* Underside of Worksurface \*




2505 Dekko Drive  
Garrett, IN 46738  
Customer Service: 800.357.5622

# ASHLEY QUAD

- Conduit -  
Above Worksurface Mounting  
Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


## Tools Required



## \*NOTE\*

All Tech Adapters Need to be Mounted in the  
↑ "UP" ↑ Position. (Refer to the back of Parts)

## 2.1 Install Data Tech Adapter Option



(Universal)

### KEYSTONE

HDMI	Optical Cable Corp 5e
Tripp-Lite	Optical Cable Corp 6
Allen-Tel	Ortronics
AMP TE-Krone	Panduit NetKey
Belden KeyConnect	Hubbell Premise
Leviton Quick Port	Type F Coax
Leviton Quick Port Extreme	ETC. (ET. AL.)

(Specific)

Belden EZ MDVO

(Specific)

Panduit Mini-COM


(Specific)

Siemon


(Specific)

Cable Retainer


## 2.2 A Install VGA Connector to VGA Tech Adapters



## B Install VGA Adapter Assembly into Unit



## 2.3 Install Blank Tech Adapter Option






2505 Dekko Drive  
Garrett, IN 46738  
Customer Service: 800.357.5622

## ASHLEY QUAD

- Conduit -  
Above Worksurface Mounting  
Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Tools Required



Screwdriver needed for optional power cord mounting clamps.

**5**

### Secure Thumb Screws and Route Conduit Option to Nearest Power Distribution Source

