

2505 Dekko Drive
Garrett, IN 46738
Customer Service: 800.357.5622

ASHLEY QUAD UNDER


- Conduit -

Under Worksurface Mounting

Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Tools Required



NOTE

All Tech Adapters Need to be Mounted in the
↑ "UP" ↑ Position. (Refer to the back of Parts)


1 Remove Data Port Cover and Blank Adapters




2 Install Data Port Options - (VGA, RJ45, HDMI, BLANK)

NOTE


See Sheet #2 for Detailed Instructions



3 Place Template and Pre-Drill Holes



4 Install Ashley Quad Under to Worksurface




ASHLEY QUAD UNDER

- Conduit -

Under Worksurface Mounting
Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Tools Required



NOTE

All Tech Adapters Need to be Mounted in the
↑ "UP" ↑ Position. (Refer to the back of Parts)

2.1 Install Data Tech Adapter Option



(Universal)

KEYSTONE

HDMI	Optical Cable Corp 5e
Tripp-Lite	Optical Cable Corp 6
Allen-Tel	Ortronics
AMP TE-Krone	Panduit NetKey
Belden KeyConnect	Hubbell Premise
Leviton Quick Port	Type F Coax
Leviton Quick Port Extreme	ETC. (ET. AL.)

(Specific)


Belden EZ MDVO

(Specific)

Panduit Mini-COM


(Specific)
Commscope(Specific)
Ortronics TrackJack(Specific)
Siemon(Specific)
Cable Retainer

2.2 A Install VGA Connector to VGA Tech Adapters


(Specific)
VGA FrontVGA
Tech Adapter
'Front'(Specific)
VGA BackVGA
ConnectorVGA
Tech Adapter
'Back'

Screws

B Install VGA Adapter Assembly into Unit

VGA
Tech Adapter Assembly

2.3 Install Blank Tech Adapter Option

Blank
Tech AdapterScrew
#15 Torx Head

Blank




2505 Dekko Drive
Garrett, IN 46738
Customer Service: 800.357.5622

ASHLEY QUAD UNDER

- Conduit -
Under Worksurface Mounting
Installation Instruction

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Tools Required



Screwdriver needed for optional power cord mounting clamps.

5

Route Conduit Option to Nearest Power Distribution Source



ASHLEY QUAD UNDER

- Conduit -
Under Worksurface Mounting
Installation Instruction Template



2505 Dekko Drive
Garrett, IN 46738
Customer Service: 800.357.5622

This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**This template is
NOT TO
SCALE!**

SUGGESTED SET BACK

1/4" SET BACK FROM FRONT EDGE

FRONT EDGE OF WORKSURFACE

FRONT OF ASHLEY412 UNDER

1/4" SET BACK FROM FRONT EDGE

**NOT TO
SCALE!**

ASHLEY QUAD UNDER DRILLING TEMPLATE

PRE-DRILL (3) HOLES

3.46"

10.0"

5.0"