




7310 Innovation Blvd., Suite 104,  
Fort Wayne, IN 46818  
Customer Service: 800.829.3101

# ASHLEY 210

- Conduit -  
Above Worksurface Mounting  
Installation Instruction


This device complies with part 15A of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Tools Required




Screwdriver needed for optional power cord mounting clamps.

### 1 Slide Bracket Behind Worksurface



### 2 Install Bottom Bracket Under the Worksurface




\* Underside of Worksurface \*



### 3 Secure Thumb Screws and Route Conduit Option to Nearest Power Distribution Source

\* Underside of Worksurface \*

Worksurface  
Thickness Range  
(3/4" to 1-1/2")



#### WIRE IDENTIFICATION

- LINE (BLACK)
- GROUND (GREEN)
- NEUTRAL (WHITE)